



Revision  
12/20/10

## **Downdraft Intake Manifolds—Part #'s 1032060, 1032061, 1032062 and 1032065**

Use a small amount of silicone on the end of each bolt when installing the bottom water plate. Due to minimal tolerances you may get water leaks from these holes if you do not use silicone on these bolts.

2031 Holly Avenue, Lake Havasu City, AZ 86404  
Office 928.505.2501 Fax 928.505.2503



Revision  
12/20/10

## **Downdraft Intake Manifolds—Part #'s 1032060, 1032061, 1032062 and 1032065**

Use a small amount of silicone on the end of each bolt when installing the bottom water plate. Due to minimal tolerances you may get water leaks from these holes if you do not use silicone on these bolts.

2031 Holly Avenue, Lake Havasu City, AZ 86404  
Office 928.505.2501 Fax 928.505.2503



Revision  
12/20/10

## **Downdraft Intake Manifolds—Part #'s 1032060, 1032061, 1032062 and 1032065**

Use a small amount of silicone on the end of each bolt when installing the bottom water plate. Due to minimal tolerances you may get water leaks from these holes if you do not use silicone on these bolts.

2031 Holly Avenue, Lake Havasu City, AZ 86404  
Office 928.505.2501 Fax 928.505.2503