



Revision
11/17/14

2RZ/3RZ Throttle Body Spacer Part #1061056



Kit contents:

1" Throttle Body spacer	1
Teflon Gasket	1
Paper Gasket	1
M8x1.25 Hex Head Bolts 60mm Long	4
M8x1.25 Hex Head Bolts 35mm Long	2
3/4" x 1" Intake Tube Spacer	2
M8 Flat Washer	6

****Before you start the installation please make sure you have all the parts listed above.****

1. Label and remove all vacuum hoses on throttle body.
2. Remove intake tube assembly.
3. Remove 2 mounting nuts and 2 mounting bolts from throttle body.
4. Remove throttle body from vehicle.
5. Remove mounting studs from intake.
6. Remove gasket and clean surface.
7. Install new spacer with Teflon gasket (the white one) between spacer and intake manifold.
8. Re-install throttle body using the 4 supplied 60mm bolts.
9. Re-install intake tube. Use 3/4"x1" spacers and supplied 35mm bolts on bottom of canister.
10. Re-install vacuum lines back onto throttle body.

NOTES:

- The small hose on the air intake will need to be routed around the passenger side of the throttle cable bracket after spacer install.
- Depending on space requirements, aftermarket intake tubes may require additional modifications (tube may need to be cut shorter).